



Advanced Depletion Extension for Reprocessing (ADER) for SERPENT 2

Daniel Wooten

October 14th, 2015

SERPENT Users Group Meeting

Outline

- The problem
- The solution
 - Chemical composition control
 - REDOX potential control
 - Removal
 - Reactivity control
- Questions

The Problem

- With renewed interest in molten-salt reactors comes a need to be able to model the fuel and salt evolution over time in these reactors
- Previous attempts to address this problem relied on code to code coupling or system specific modifications to existing codes [2][1].
- No chemistry control
- No REDOX control

The Solution

- Modify SERPENT-2 to allow a user to specify for any material...
 - Relationships between groups of chemical, elemental, or isotopic constituents
 - Ranges of compositions for materials
 - Continuous and discrete removal and feed of chemicals, elements and isotopes
 - The average oxidation state as well as the average oxidation state of elements
 - Compositions of feed materials to be used as makeup material, or fuel, if needed to satisfy other constraints
 - Ranges of acceptable reactivity for a system as well as the “reactivity weight”

Chemistry/Composition Control

- This portion of the modification allows for complete or partial control of a material's makeup.
- Material -> Group(s) -> Element(s) -> Isotope(s)
- Material
 - Group_i[min – max]
 - Element_{i,j}[min – max]
 - Isotope_{i,j,k}[min – max]
- Groups in materials may have variable ratios with other groups
 - Group_a [min – max] : Group_b

Chemistry/Composition Control

Group 001	Group 002	Group 003	Group 004
F 0.57	U [0.2 – 0.25] U-233 [0.2 – 0.3] U-238 [0.7 – 0.8]	Th 1.0	F 1.0
Li 0.29	F [rem]		
Be 0.14			

Material: Salt
Group 001 [0.33 , 0.66]
Group 002 [0 , 0.42]
Group 003 [0.20 , rem]
001 [1 , 3] : 002
004 [3 , 4] : 003

Chemistry/Composition Control

- Linear optimization is used to find the ratios and ranges which will satisfy the constraints
- Users may pick the optimization target though a default is provided

Chemistry/Composition Control

Feed 100 - C	Feed 200 - C	Feed 300 - D	Removal 400 - C	Removal 500 - D
F 0.57	U 0.2 U-233 1.0	Th 0.2	F 0.57	U 1.0
Li 0.29 Li-6 0.0001 Li-7 0.9999	F 0.8	F 0.8	Li 0.29 Li-6 all Li-7 rem	
Be 0.14			Be 0.14	

Chemistry/Composition Control

- Per material, an element or isotope may be specified to be completely accounted for in the groups assigned to said material

H – no

He – no

....

U – yes

....

Am - no

- All elements and isotopes in a material DO NOT have to be a part of a group

REDOX Potential Control

- Not actually REDOX – oxidation state control
- Inputs:
 - Material: [Min Oxidation – Max Oxidation]
 - Elements: Oxidation , weight

R - Feed 100 - C	R - Feed 200 - D	R - Removal 400 - C
F 1.0	Li 1.0 Li-6 0.0001 Li-7 0.9999	F 0.57
		Li 0.43 Li-6 all Li-7 rem


Removal

- Continuous proportional removal will be supported much in the same way it was in SERPENT-2.1.24; except each material may have its own
- Additionally, discreet and continuous removal based on groups

Removal 900 - C	Removal 800 - D
Np 0.2	U 0.2 U-238 – 0.8 U-233 – 0.2
F 0.8	F 0.8

Removal

- If time allows, removal rate search feature



Reactivity Control

- k_{eff} [min – max]
- $k_{eff} \approx \rho_L \times \frac{\sum_n^N v^n \Sigma_f^n}{\sum_n^N \Sigma_a^n}$
- $k_{eff} \approx \rho_L \times \sum_m^M \left(\frac{\sum_n^N v^{m,n} \Sigma_f^{m,n}}{\sum_n^N \Sigma_a^{m,n}} \times w_m \right)$

Reactivity Control

ρ - Feed 100 - C	ρ - Feed 200 - D	ρ - Removal 400 - C
U 0.2 U-233 0.0495 U-238 0.9505	Pu 0.3333 P-239 0.23 P-240 0.77	U 1.0 U-233 1.0
F 0.8	F 0.6667	

I would like to acknowledge the following people for their contributions to my ongoing efforts

Dr. Max Fratoni

Dr. Manuele Aufiero

Dr. Jaakko Leppänen

Lars Jorgensen

Dr. Katherine Huff



References

1. Aufiero, M., A. Cammi, C. Fiorina, J. Leppänen, L. Luzzi, and M. E. Ricotti. “An Extended Version of the SERPENT-2 Code to Investigate Fuel Burn-up and Core Material Evolution of the Molten Salt Fast Reactor.” *Journal of Nuclear Materials* 441, no. 1 (2013): 473–86.
2. Trelue, Holly, and David Poston. “User’s Manual, Version 2.0 for Monteburns, Version 5B.” Los Alamos Scientific Laboratory of the University of California, September 1, 1999.